

TILE SPACER

FOR A PERFECTLY UNIFORM JOINT WIDTH



HIGH PRECISION

Ensures a consistent joint width for a perfect finish.





EASY TO USE

Quick and easy way to achieve a consistent joint width.

TECHNICAL SPECIFICATIONS

Item	Classic tile spacer
Material	Polypropylene
Leg length	28 mm
Colour	White
Joint width	1.5 – 2 – 3 – 4 – 5 mm 6 – 7 – 8 – 10 mm
Packaging	✓ 200 pcs ✓ 250 pcs ✓ 500 pcs

HOW TO USE IN 3 STEPS



APPLY ADHESIVE

Apply sufficient tile adhesive and place the first tile. Check that it is perfectly level.

INSERT THE SPACER

Place the next tiles. Position one tile spacer between the tile edges at each intersection of four tile corners.

CURING

Leave the tile spacers in place. Once the adhesive has almost fully cured, remove the tile spacers from the joint using tile spacer pliers.



DESIGNED FOR PROFESSIONALS

Durable, efficient and reliable.